

ATOM QUICK GUIDE 2019

UPGRADE KITS



Bluetooth + App Premium

App Store:
BH Bikes premium

Google Play:
BH Bikes premium




GPS Tracker



Winter Battery Cover

DISPLAY INFO



ON / OFF




CHANGE INFO



3 sec



LEVEL



LIGHTS



3 sec




THROTTLE




3 sec


Exit




Reset Trip




Display Info




Brightness



Units




System Status - Battery Status




System Status - Motor Settings


Motor Settings Assistance




Motor Settings Acceleration




Wheel Size





Language



Errors



BATTERY



Only use the charger provided with the battery. Do not place any object on the charger.
Charging the BH EMOTION battery at 70-80% is mandatory if not used or stored for a long time period. Additionally, control the level of the battery charger every 3 months and always keep it above 20% charge. If the battery is in deep sleep mode, in order to wake it up, please charge the battery to 100% capacity.