

ATOM QUICK GUIDE 2020

UPGRADE KITS



Bluetooth + App Premium

App Store:
BH Bikes premium

Google Play:
BH Bikes premium



GPS Tracker


App Store:
BH Bikes GPS Locator

Google Play:
BH Bikes premium




Winter Battery Cover

DISPLAY INFO



LEVEL



LIGHTS



SETTINGS

3 sec

Enter

Exit

3 sec

Reset Trip

Display Info

Brightness

Units

System Status







Motor Settings Assistance & Acceleration

Wheel Size



Language

Errors

DISPLAY INFO



BATTERY



Only use the charger provided with the battery. Do not place any object on the charger.
Charging the BH battery to 70-80% is mandatory if not used or stored for a long time period.
Additionally, control the level of the battery charger every 3 months and keep it above 20% charge.
If the battery is in deep sleep mode, in order to wake it up, please charge the battery to 100%.